

Liste des imprimantes compatible avec le Pocket ECG – ECG001

BROTHER :

- PRINTER_MODEL_ENUM0("•Brother DCP-L2550DW"),
- PRINTER_MODEL_ENUM1("•Brother DCP-L2535DW"),
- PRINTER_MODEL_ENUM2("•Brother DCP-B7520DW"),
- PRINTER_MODEL_ENUM3("•Brother DCP-B7535DW"),
- PRINTER_MODEL_ENUM4("•Brother HL-2595DW"),
- PRINTER_MODEL_ENUM5("•Brother DCP-7195DW"),
- PRINTER_MODEL_ENUM6("•Brother MFC-B7720DN"),
- PRINTER_MODEL_ENUM7("•Brother DCP-B7530DN"),
- PRINTER_MODEL_ENUM8("•Brother DCP-B7500D"),
- PRINTER_MODEL_ENUM9("•Brother HL-B2050DN"),
- PRINTER_MODEL_ENUM10("•Brother MFC-L8900CDW"),
- PRINTER_MODEL_ENUM11("•Brother MFC-8540DN"),
- PRINTER_MODEL_ENUM12("•Brother MFC-8535DN"),
- PRINTER_MODEL_ENUM13("•Brother MFC-8530DN"),
- PRINTER_MODEL_ENUM14("•Brother MFC-7880DN"),
- PRINTER_MODEL_ENUM15("•Brother DCP-7180DN"),
- PRINTER_MODEL_ENUM16("•Brother DCP-L8400CDN"),
- PRINTER_MODEL_ENUM17("•Brother MFC-L8650CDW"),
- PRINTER_MODEL_ENUM18("•Brother HL-L9310CDW"),
- PRINTER_MODEL_ENUM19("•Brother HL-L8260CDN"),
- PRINTER_MODEL_ENUM20("•Brother HL-5595DN"),
- PRINTER_MODEL_ENUM21("•Brother HL-5590DN"),
- PRINTER_MODEL_ENUM22("•Brother HL-5585D"),
- PRINTER_MODEL_ENUM23("•Brother HL-5580D"),
- PRINTER_MODEL_ENUM24("•Brother HL-L9200CDW"),
- PRINTER_MODEL_ENUM25("•Brother HL-6180DW"),
- PRINTER_MODEL_ENUM26("•Brother HL-5450DN"),
- PRINTER_MODEL_ENUM27("•Brother HL-5440D"),
- PRINTER_MODEL_ENUM28("•Brother HL-5445D"),
- PRINTER_MODEL_ENUM29("•Brother HL-3170CDW"),
- PRINTER_MODEL_ENUM30("•Brother DCP-7190DW"),
- PRINTER_MODEL_ENUM31("•Brother DCP-7090DW"),
- PRINTER_MODEL_ENUM32("•Brother HL-5595DNH"),
- PRINTER_MODEL_ENUM33("•Brother HL-3160CDW"),
- PRINTER_MODEL_ENUM34("•Brother HL-3190CDW"),
- PRINTER_MODEL_ENUM35("•Brother DCP-9030CDN"),
- PRINTER_MODEL_ENUM36("•Brother MFC-9150CDN"),
- PRINTER_MODEL_ENUM37("•Brother MFC-9350CDW"),
- PRINTER_MODEL_ENUM38("•Brother MFC-1816"),
- PRINTER_MODEL_ENUM39("•Brother MFC-1819"),
- PRINTER_MODEL_ENUM40("•Brother MFC-7470D"),
- PRINTER_MODEL_ENUM41("•Brother MFC-9340CDW"),
- PRINTER_MODEL_ENUM42("•Brother MFC-9140CDN"),
- PRINTER_MODEL_ENUM43("•Brother DCP-9020CDN"),
- PRINTER_MODEL_ENUM44("•Brother MFC-7895DW"),
- PRINTER_MODEL_ENUM45("•Brother DCP-8060"),
- PRINTER_MODEL_ENUM46("•Brother DCP-8070D"),

- PRINTER_MODEL_ENUM47("•Brother DCP-8085DN"),
- PRINTER_MODEL_ENUM48("•Brother DCP-B7535DW"),
- PRINTER_MODEL_ENUM49("•Brother HL-2250DN"),
- PRINTER_MODEL_ENUM50("•Brother HL-2560DN"),
- PRINTER_MODEL_ENUM51("•Brother HL-5340D"),
- PRINTER_MODEL_ENUM52("•Brother HL-5350DN"),
- PRINTER_MODEL_ENUM53("•Brother HL-5370DW"),
- PRINTER_MODEL_ENUM54("•Brother HL-5595DN(H)'),
- PRINTER_MODEL_ENUM55("•Brother MFC-7840N"),
- PRINTER_MODEL_ENUM56("•Brother MFC-7860DN"),
- PRINTER_MODEL_ENUM57("•Brother MFC-8370DN"),
- PRINTER_MODEL_ENUM58("•Brother MFC-8460N"),
- PRINTER_MODEL_ENUM59("•Brother MFC-8510DN"),
- PRINTER_MODEL_ENUM60("•Brother MFC-8515DN"),
- PRINTER_MODEL_ENUM61("•Brother MFC-8520DN"),
- PRINTER_MODEL_ENUM62("•Brother MFC-8860DN"),
- PRINTER_MODEL_ENUM63("•Brother MFC-8880DN"),

HP :

- PRINTER_MODEL_ENUM64("•HP Color LaserJet 2820"),
- PRINTER_MODEL_ENUM65("•HP Color LaserJet 2840"),
- PRINTER_MODEL_ENUM66("•HP Color LaserJet CM1015 MFP"),
- PRINTER_MODEL_ENUM67("•HP Color LaserJet CM1017 MFP"),
- PRINTER_MODEL_ENUM68("•HP LaserJet 3050"),
- PRINTER_MODEL_ENUM69("•HP LaserJet 3050z"),
- PRINTER_MODEL_ENUM70("•HP LaserJet 3052"),
- PRINTER_MODEL_ENUM71("•HP LaserJet 3055"),
- PRINTER_MODEL_ENUM72("•HP LaserJet 3390"),
- PRINTER_MODEL_ENUM73("•HP LaserJet M3027 MFP"),
- PRINTER_MODEL_ENUM74("•HP LaserJet M3035 MFP"),
- PRINTER_MODEL_ENUM75("•HP LaserJet M4345 MFP"),
- PRINTER_MODEL_ENUM76("•HP LaserJet M5025 MFP"),
- PRINTER_MODEL_ENUM77("•HP LaserJet M5035 MFP"),
- PRINTER_MODEL_ENUM78("•HP Color LaserJet 4730mf"),
- PRINTER_MODEL_ENUM79("•HP Color LaserJet 9500mf"),
- PRINTER_MODEL_ENUM80("•HP LaserJet 4345mf"),
- PRINTER_MODEL_ENUM81("•HP LaserJet 9040mf"),
- PRINTER_MODEL_ENUM82("•HP LaserJet 9050mf"),
- PRINTER_MODEL_ENUM83("•HP Color LaserJet 2605"),
- PRINTER_MODEL_ENUM84("•HP Color LaserJet 2700"),
- PRINTER_MODEL_ENUM85("•HP Color LaserJet 5550"),
- PRINTER_MODEL_ENUM86("•HP LaserJet 1320"),
- PRINTER_MODEL_ENUM87("•HP LaserJet 5200Lx"),
- PRINTER_MODEL_ENUM88("•HP LaserJet 5200L"),
- PRINTER_MODEL_ENUM89("•HP LaserJet 5200"),
- PRINTER_MODEL_ENUM90("•HP LaserJet 5200n"),
- PRINTER_MODEL_ENUM91("•HP LaserJet 5200dtn"),
- PRINTER_MODEL_ENUM92("•HP LaserJet 5200tn"),
- PRINTER_MODEL_ENUM93("•HP LaserJet 9040"),
- PRINTER_MODEL_ENUM94("•HP LaserJet 9050dn"),

- PRINTER_MODEL_ENUM95("•HP LaserJet 9050n"),
- PRINTER_MODEL_ENUM96("•HP LaserJet 9050"),
- PRINTER_MODEL_ENUM97("•HP LaserJet P2015"),
- PRINTER_MODEL_ENUM98("•HP LaserJet P3005"),
- PRINTER_MODEL_ENUM99("•HP LaserJet M1005"),
- PRINTER_MODEL_ENUM100("•HP Deskjet F388"),
- PRINTER_MODEL_ENUM101("•HP LASERJET PRO M227FDW"),
- PRINTER_MODEL_ENUM102("•HP LASERJET PRO M180N"),
- PRINTER_MODEL_ENUM103("•HP LASERJET PRO M154A"),
- PRINTER_MODEL_ENUM104("•HP LASERJET PRO M280NW"),
- PRINTER_MODEL_ENUM105("•HP LASERJET E78325DN"),
- PRINTER_MODEL_ENUM106("•HP LASERJET E78330Z"),
- PRINTER_MODEL_ENUM107("•HP LASERJET E78325Z"),
- PRINTER_MODEL_ENUM108("•HP LASERJET E78323Z"),
- PRINTER_MODEL_ENUM109("•HP LASERJET E78330DN"),
- PRINTER_MODEL_ENUM110("•HP LASERJET E78323DN"),
- PRINTER_MODEL_ENUM111("•HP LASERJET E78228DN"),
- PRINTER_MODEL_ENUM112("•HP LASERJET E78223DN"),
- PRINTER_MODEL_ENUM113("•HP LASERJET ENTERPRISE 700 MFP M725Z"),
- PRINTER_MODEL_ENUM114("•HP LASERJET ENTERPRISE 700 MFP M725F"),
- PRINTER_MODEL_ENUM115("•HP LASERJET ENTERPRISE 700 MFP M725DN"),
- PRINTER_MODEL_ENUM116("•HP COLOR LASERJET ENTERPRISE MFP M776DN"),
- PRINTER_MODEL_ENUM117("•HP COLOR LASERJET ENTERPRISE FLOW MFP M776ZS"),
- PRINTER_MODEL_ENUM118("•HP COLOR LASERJET ENTERPRISE FLOW MFP M776Z"),
- PRINTER_MODEL_ENUM119("•HP COLOR LASERJET MFP E77830DN"),
- PRINTER_MODEL_ENUM120("•HP COLOR LASERJET FLOW MFP E77830Z"),
- PRINTER_MODEL_ENUM121("•HP COLOR LASERJET MFP E77825DN"),
- PRINTER_MODEL_ENUM122("•HP LASERJET MFP E72535DN"),
- PRINTER_MODEL_ENUM123("•HP LASERJET FLOW MFP E72535Z"),
- PRINTER_MODEL_ENUM124("•HP LASERJET MFP E72530DN"),
- PRINTER_MODEL_ENUM125("•HP LASERJET FLOW MFP E72530Z"),
- PRINTER_MODEL_ENUM126("•HP LASERJET MFP E72525DN"),
- PRINTER_MODEL_ENUM127("•HP LASERJET FLOW MFP E72525Z"),
- PRINTER_MODEL_ENUM128("•HP COLOR LASERJET MANAGED MFP E77428DN"),
- PRINTER_MODEL_ENUM129("•HP COLOR LASERJET MANAGED MFP E77422DN"),
- PRINTER_MODEL_ENUM130("•HP LASERJET MANAGED MFP E72430DN"),
- PRINTER_MODEL_ENUM131("•HP LASERJET MANAGED MFP E72425DN"),
- PRINTER_MODEL_ENUM132("•HP COLOR LASERJET FLOW MFP E87660Z"),
- PRINTER_MODEL_ENUM133("•HP COLOR LASERJET MANAGED MFP E87660DU"),
- PRINTER_MODEL_ENUM134("•HP COLOR LASERJET FLOW MFP E87650Z"),
- PRINTER_MODEL_ENUM135("•HP COLOR LASERJET MANAGED MFP E87650DU"),
- PRINTER_MODEL_ENUM136("•HP COLOR LASERJET FLOW MFP E87640Z"),
- PRINTER_MODEL_ENUM137("•HP COLOR LASERJET MANAGED MFP E87640DU"),
- PRINTER_MODEL_ENUM138("•HP LASERJET FLOW MFP E82560Z"),
- PRINTER_MODEL_ENUM139("•HP LASERJET MANAGED MFP E82560DU"),
- PRINTER_MODEL_ENUM140("•HP LASERJET MANAGED MFP E82550DU"),
- PRINTER_MODEL_ENUM141("•HP LASERJET MANAGED MFP E82540DU"),
- PRINTER_MODEL_ENUM142("•HP LASERJET MFP M72625DN"),
- PRINTER_MODEL_ENUM143("•HP LASERJET MFP M42525DN"),
- PRINTER_MODEL_ENUM144("•HP LASERJET MFP M42525N"),
- PRINTER_MODEL_ENUM145("•HP LASERJET MFP M42523DN"),

- PRINTER_MODEL_ENUM146("•HP LASERJET MFP M42523N"),
- PRINTER_MODEL_ENUM147("•HP LASERJET MFP M439NDA"),
- PRINTER_MODEL_ENUM148("•HP LASERJET MFP M439DN"),
- PRINTER_MODEL_ENUM149("•HP LASERJET MFP M439N"),
- PRINTER_MODEL_ENUM150("•HP LASERJET MFP M437NDA"),
- PRINTER_MODEL_ENUM151("•HP LASERJET MFP M437DN"),
- PRINTER_MODEL_ENUM152("•HP LASERJET MFP M437N"),
- PRINTER_MODEL_ENUM153("•HP LASERJET ENTERPRISE FLOW M830Z MFP"),
- PRINTER_MODEL_ENUM154("•HP COLOR LASERJET ENTERPRISE FLOW M880Z"),
- PRINTER_MODEL_ENUM155("•HP LASERJET MFP M72630DN"),
- PRINTER_MODEL_ENUM156("•HP COLOR LASERJET PRO M454DW"),
- PRINTER_MODEL_ENUM157("•HP COLOR LASERJET PRO M454DN"),
- PRINTER_MODEL_ENUM158("•HP COLOR LASERJET PRO M454NW"),
- PRINTER_MODEL_ENUM159("•HP LASERJET PRO M405DW"),
- PRINTER_MODEL_ENUM160("•HP LASERJET PRO M405DN"),
- PRINTER_MODEL_ENUM161("•HP LASERJET PRO M405D"),
- PRINTER_MODEL_ENUM162("•HP LASERJET PRO M405N"),
- PRINTER_MODEL_ENUM163("•HP LASERJET PRO M305DN"),
- PRINTER_MODEL_ENUM164("•HP LASERJET PRO M305D"),
- PRINTER_MODEL_ENUM165("•HP COLOR LASERJET PRO MFP M479FDW"),
- PRINTER_MODEL_ENUM166("•HP COLOR LASERJET PRO MFP M479FNW"),
- PRINTER_MODEL_ENUM167("•HP COLOR LASERJET PRO MFP M479DW"),
- PRINTER_MODEL_ENUM168("•HP LASERJET PRO MFP M429FDW"),
- PRINTER_MODEL_ENUM169("•HP LASERJET PRO MFP M429FDN"),
- PRINTER_MODEL_ENUM170("•HP LASERJET PRO MFP M429DW"),
- PRINTER_MODEL_ENUM171("•HP LASERJET PRO MFP M329DN"),
- PRINTER_MODEL_ENUM172("•HP LASERJET PRO MFP M329DW"),
- PRINTER_MODEL_ENUM173("•HP LASERJET PRO M435NW"),
- PRINTER_MODEL_ENUM174("•HP LASERJET MFP M436N A3"),
- PRINTER_MODEL_ENUM175("•HP LASERJET MFP M436NDA A3"),
- PRINTER_MODEL_ENUM176("•HP LASERJET PRO M227SDN"),
- PRINTER_MODEL_ENUM177("•HP LASERJET PRO M154NW"),
- PRINTER_MODEL_ENUM178("•HP LASERJET PRO M254NW"),
- PRINTER_MODEL_ENUM179("•HP LASERJET PRO M254DW"),
- PRINTER_MODEL_ENUM180("•HP LASERJET PRO M181FW"),
- PRINTER_MODEL_ENUM181("•HP LASERJET PRO M281FDW"),
- PRINTER_MODEL_ENUM182("•HP LASERJET PRO MFP M227D"),
- PRINTER_MODEL_ENUM183("•HP LASERJET PRO MFP M227FDN"),
- PRINTER_MODEL_ENUM184("•HP LASERJET PRO M203D"),
- PRINTER_MODEL_ENUM185("•HP LASERJET FLOW MFP E82540Z"),
- PRINTER_MODEL_ENUM186("•HP LASERJET FLOW MFP E82550Z"),
- PRINTER_MODEL_ENUM225("•HP M202dw"),
- PRINTER_MODEL_ENUM226("•HP M283FDW"),
- PRINTER_MODEL_ENUM227("•HP M148fdw"),
- PRINTER_MODEL_ENUM228("•HP M148dw");
- PRINTER_MODEL_ENUM225("•HP M202dw"),
- PRINTER_MODEL_ENUM226("•HP M283FDW"),
- PRINTER_MODEL_ENUM227("•HP M148fdw"),
- PRINTER_MODEL_ENUM228("•HP M148dw");

EPSON :

- PRINTER_MODEL_ENUM187("•Epson M15188"),
- PRINTER_MODEL_ENUM188("•Epson L15188"),
- PRINTER_MODEL_ENUM189("•Epson WF-6093"),
- PRINTER_MODEL_ENUM190("•Epson WF-6593"),
- PRINTER_MODEL_ENUM191("•Epson WF-C869Ra"),
- PRINTER_MODEL_ENUM192("•Epson WF-C20590a"),
- PRINTER_MODEL_ENUM193("•Epson WF-C17590a"),
- PRINTER_MODEL_ENUM194("•Epson WF-C5790a"),
- PRINTER_MODEL_ENUM195("•Epson WF-C5290a"),
- PRINTER_MODEL_ENUM196("•Epson WF-C8190a"),
- PRINTER_MODEL_ENUM197("•Epson WF-C8690a"),
- PRINTER_MODEL_ENUM198("•Epson WF-C579Ra"),
- PRINTER_MODEL_ENUM199("•Epson WF-C20590c"),
- PRINTER_MODEL_ENUM200("•Epson WF-M20590a"),
- PRINTER_MODEL_ENUM201("•Epson WF-C17590c"),
- PRINTER_MODEL_ENUM202("•Epson WF-M20590B"),
- PRINTER_MODEL_ENUM203("•Epson WF-M20590c"),
- PRINTER_MODEL_ENUM204("•Epson WF-C879Ra"),
- PRINTER_MODEL_ENUM205("•Epson WF-C878Ra"),
- PRINTER_MODEL_ENUM206("•Epson WF-M21000a"),
- PRINTER_MODEL_ENUM207("•Epson WF-M21000c"),

CANON :

- PRINTER_MODEL_ENUM208("•Canon LBP162dw"),
- PRINTER_MODEL_ENUM209("•Canon LBP722Cx"),
- PRINTER_MODEL_ENUM210("•Canon MF543dw"),
- PRINTER_MODEL_ENUM211("•Canon LBP223dw"),
- PRINTER_MODEL_ENUM212("•Canon LBP225dn"),
- PRINTER_MODEL_ENUM213("•Canon LBP228x"),
- PRINTER_MODEL_ENUM214("•Canon MF449dw"),
- PRINTER_MODEL_ENUM215("•Canon MF443dw"),
- PRINTER_MODEL_ENUM216("•Canon MF441dw"),
- PRINTER_MODEL_ENUM217("•Canon MF643Cdw"),
- PRINTER_MODEL_ENUM218("•Canon MF645Cx"),
- PRINTER_MODEL_ENUM219("•Canon LBP623Cdn"),
- PRINTER_MODEL_ENUM220("•Canon LBP623Cdw"),
- PRINTER_MODEL_ENUM221("•Canon LBP663Cdw"),
- PRINTER_MODEL_ENUM222("•Canon MF266dn"),
- PRINTER_MODEL_ENUM223("•Canon MF269dw"),
- PRINTER_MODEL_ENUM224("•Canon LBP710Cx"),